

Covering With Wood Deck

When installing a wood deck over an EPDM membrane, the deck sleepers should be laid over an extra piece of membrane called a separator sheet. The separator sheet should extend a minimum of two inches (2") past the sleeper on all sides and should be adhered with *Seam Tape*.

